

# Drawing Apps Don't Show on The Tablet Monitor

If your drawing apps only show on the desktop screen, and the tablet monitor shows a background image only, that means you are working on extended display mode.

There are two methods you can let your apps open show on the tablet monitor:

Method 1: Open your computer display setting, and confirm how the monitors are arranged. For example, the tablet monitor is placed on the right of your computer monitor. In this case, click and drag the windows opened to the right of your computer monitor, then it will show on the tablet monitor.

Method 2: Open your computer display setting, and change the display mode to duplicate.

For Windows computers, right-click on the desktop screen, and go to display settings.

Then scroll down to multiple displays and change the option to 'duplicate' .

For Mac computers, open Mac preference, go to the display setting, click arrangement, then select mirror displays to duplicate the monitors.

For further questions, please write an email to [service@xp-pen.com](mailto:service@xp-pen.com).